Autonics

# Comprehensive Motion Control Management Software



## atMotion CATALOG

For your safety, read and follow the considerations written in the instruction manual, other manuals and Autonics website.

The specifications, dimensions, etc. are subject to change without notice for product improvement. Some models may be discontinued without notice.

#### Features

- Supports Multiple Devices
- Simple Graphic User Interface
- Multilingual Support

#### Installation Specification

Download the installation program from the Autonics website.	
Item	Minimum requirements
System	IBM PC compatible computer with over Pentium III
OS	Microsoft Windows 98 / NT / XP / Vista / 7 / 8 / 10
RAM	256 MB or higher
Storages	At least 1 GB of available HDD space
Resolution	1024 × 768 or higher
Others	RS232C Serial port (9-pin), USB port

#### Manual

Please refer to the manual for correct use of the product and be sure to follow the precautions.

Download the manual from the Autonics website.

### **Supported Device**

#### Motion Controller Devices of Autonics

Supported devices will be updated continuously. You can check the supported devices from the list of supported devices in the software. For more information, refer to the manual of the supported device.