

### **GENERAL DESCRIPTION**

The device DAT 3590 is an isolated repeater between asynchronous serials lines RS485 or RS422 that guarantees a full isolation between power supply and serial line removing eventual ground-loop effects, allowing the use of the device even in the heavy environmental conditions. It is designed to operate either on serial interface RS-422 full-duplex 4 wires or RS485 half-duplex 2 wires, with a baud-rate transmission up to 115.2 Kbps.

The transmission is asynchronous without settings of protocol, data format and baud rate.

The DAT 3590 is in compliance with the Directive UL 61010-1 for US market and with the Directive CSA C22.2 No 61010-1 for the Canadian market. The device is housed in a rough self-extinguishing plastic container which, thanks to its thin profile of 22.5 mm only, allows a high density mounting on EN-50022 standard DIN rail.

#### USER INSTRUCTIONS

Before to install the device, please read the "Installation Instruction" section.

The device DAT 3590 transmits the data incoming on the RS-485 (2 wires) or RS-422 (4 wires) in bidirectional mode; the data incoming on the line RX (pins D-E for RS-485 or B-C for RS-422) are isolated and transmitted on the line TX (pins D-E).

The transmission of the signal follows the logic state of every single bit, then there is not necessary to set the protocol, the data format and the baudrate.

When the data transmission is off, the RS-485 driver is in the receive condition (high impedance); when the data transmission goes on the RS-485 driver switch immediately to the transmission condition (low impedance). The low impedance is kept for about 150 us, then the line returns automatically in high impedance to keep free the line in case of error.

## TECHNICAL SPECIFICATIONS (Typical @ 25 °C and in the nominal conditions)

In compliance with standard		ISOLATION	
RS485 Interface Baud-rate	RS485 and RS422 up to 115.2 Kbps	Power supply / RS485-422 RS485-422 / RS485-422	2000 Vac, 50 Hz, 1 min. 2000 Vac, 50 Hz, 1 min.
Max. distance / baud-rate ratio (recommended) (1) Number of modules in multipoint	1.2 Km – 4000 ft @ 38400 bps 2 Km – 6560 ft @ 19200 bps 3 Km – 9840 ft @ 9600 bps 4 Km – 13100 ft @ 4800 bps 5 Km – 16400 ft @ 2400 bps 7 Km – 23000 ft @ 1200 bps up to 32	<b>ÉNVIRONMENTAL CONDIT</b> Operative Temperature UL Operative Temperature Storage Temperature Humidity (not condensed) Maximum Altitude Installation Category of installation Pollution Degree	-20°C +60°C
Switching time TX/RX (RS485)	150 us.	MECHANICAL SPECIFICATIONS Material Self-extinguish plastic	
Internal terminator resistance (optional) 120 Ohm		IP Code Wiring	Self-extinguish plastic IP20 wires with diameter
<b>POWER SUPPLY</b> Power supply DC voltage Reverse polarity protection Power supply AC voltage	10 30 Vdc 60 Vdc max 9 ÷ 18 Vac (18 ÷ 30 Vac optional)	Tightening Torque Mounting Weight	0.8÷2.1 mm <sup>2</sup> /AWG 14-18 0.5 N m in compliance with DIN rail standard EN-50022 about 160 g.
Current consumption	35 mA max.	CERTIFICATIONS EMC ( for industrial environ Immunity Emission	n <b>ments)</b> EN 61000-6-2 EN 61000-6-4
RS-485/422	removable screw terminals	UL US Standard Canadian Standard CCN Typology	UL 61010-1 CSA C22.2 No 61010-1 NRAQ/NRAQ7 Open Type device
(1) – The maximum distance depends of: number of devices connected, type of cabling, noises, etc		Classification File Number	Industrial Control Equipment E352854

# **INSTALLATION INSTRUCTIONS**


The DAT 3590 is suitable for fitting to DIN rails in the vertical position. For optimum operation and long life follow these instructions:

When the devices are installed side by side it may be necessary to separate them by at least 5 mm in the following case:

- If panel temperature exceeds 45°C and high power supply value( > 27 Vdc).


Make sure that sufficient air flow is provided for the device avoiding to place raceways or other objects which could obstruct the ventilation slits. Moreover it is suggested to avoid that devices are mounted above appliances generating heat; their ideal place should be in the lower part of the panel. Install the device in a place without vibrations.

Moreover it is suggested to avoid routing conductors near power signal cables (motors, induction ovens, inverters, etc...) and to use shielded cable for connecting signals.




# LIGHT SIGNALLING


LED	COLOUR	STATE	DESCRIPTION	
PWR	GREEN	ON	Device powered Device not powered / Wrong RS-485 cabling.	
		OFF		
		RAPID BLINK	Communication in progress (blink frequency depends to baud-rate)	




# <u>WIRING</u>



### RS485





## **ISOLATION STRUCTURE**



